

Soft-Sided Collapsible Crates



1. Remove top support bars from storage pocket on bottom of crate.



2. Unfold front and back of frame into an upright position. Unzip top opening of crate.



3. Attach top support bar to top corner of crate. Push in on center of bar to compress the spring.



- 4. Fit opposite end of bar into the opposite corner of the crate.
- 5. Repeat steps 3 & 4 with other support bar.



6. Fully assembled Stroller

To disassemble:

- 1. Unzip top opening of crate.
- 2. Push in on the tension spring and remove each top support bar.
- 3. Fold down front and back of frame.

Care and Maintenance: Wipe frame and fabric clean with a damp cloth using a mild soap and water. Let air dry. Store in a clean, dry place.

Caution: Do not leave pet unsupervised. Recommended for pets only. Not recommended for puppies and chronic chewers.

Date Purchased:______Model #:_____